ENGINEERING
TOMORROW

Installation Guide

ASV-PV / DN 32-50 service kit 5-25 / 20-60 / 20-80

= AUTO =		3,5 - 4,5 mm × 0,7mm

1



2



3



4



© Danfoss | 2016.11





Spring replacement
ASV-PV 5-25 kPa > ASV-PV 20-60 kPa
ASV-PV 20-60 kPa > ASV-PV 5-25 kPa
ASV-PV 5-25 kPa > ASV-PV 20-80 kPa
ASV-PV 20-60 kPa > ASV-PV 20-80 kPa







Setting scale replacement



© Danfoss | 2016.11 | 3

ASV-PV / DN 32-50 service kit 5-25 / 20-60 / 20-80

4



5



6







7



Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.